465N-6407-0096 FLASH PATTERN

LIGHTBAR LAMP CONFIGURATION

DF3 DF2 DF1 FC PF1 PF2 PF3
DC PC

MODE	CONTROL WIRES ACTIVATED	LAMP OPERATION
		FRONT / CORNER STROBES
1	RED/WHT	DC ALTERNATES WITH PC
SWEEP PATTERN	ORG	DF3, DF2, DF1, FC, PF1, PF2, PF3, PF2, PF1, FC, DF1, DF2, REPEAT (SWEEP)
ARROW	BLU or BLU & ORG	DF3, DF3 & DF2, DF2 & DF1, DF1 & FC, FC & PF1, PF1 & PF2, PF2 & PF3, PF3, PAUSE REPEAT (ARROW)
ARROW	WHT/BLK or WHT/BLK & ORG	PF3, PF3 & PF2, PF2 & PF1, PF1 & FC, FC & DF1, DF1 & DF2, DF2 & DF3, DF3, PAUSE REPEAT (ARROW)
CENTER OUT	BLU & WHT/BLK or BLU & WHT/BLK & ORG	FC, DF1 & FC & PF1, DF2 & DF1 & PF1 & PF2, DF3 & DF2 & PF2 & PF3, DF3 & PF3, PAUSE REPEAT (CENTER OUT)

NOTE: GREEN control wire activates high intensity to strobes.
Apply +12vdc to appropriate control wire to activate desired function.