930N-4805-0030 FLASH PATTERN

LIGHTBAR LAMP CONFIGURATION

DF2 DF1 FC PF1 PF2
DC PC
DA PA
DR2 DR1 RC PR1 PR2

MODE	CONTROL WIRES ACTIVATED	LAMP OPERATION	
		REAR / ALLEY STROBES	FRONT / CORNER STROBES
1	ORG (REAR ONLY)	DR2, DR1, RC, PR1, PR2, PR1, RC, DR1, REPEAT (SWEEP) DA ALTERNATES WITH PA	NONE
2	ORG & BLU (FRONT ONLY)	DA ALTERNATES WITH PA	DF2, DF1, PF1, PF2, PF1, DF1, REPEAT (SWEEP) DC ALTERNATES WITH PC
3	ORG & BLU & WHT/BLK (360 +)	SAME AS MODE 1 (SWEEP)	SAME AS MODE 2 (SWEEP)
RIGHT ARROW	BLU	DR2, DR2 & DR1, DR1 & RC, RC & PR1, PR1 & PR2, PR2, DA & PA, REPEAT	SAME AS MODE 2 (SWEEP)
LEFT ARROW	WHT/BLK	PR2, PR2 & PR1, PR1 & RC, RC & DR1, DR1 & DR2, DR2, DA & PA, REPEAT	SAME AS MODE 2 (SWEEP)
CENTER OUT	BLU & WHT/BLK	RC, DR1 & RC & PR1, DR2 & DR1 & PR1 & PR2, DR2 & PR2, DA & PA, REPEAT	SAME AS MODE 2 (SWEEP)

NOTE: GROUNDING the GREEN control wire activates low intensity to strobes. Apply +12vdc to all other control wires to activate desired function.

CONTROL WIRES FOR OPTIONAL HALOGENS

CONTROL WIRE ACTIVATED		HALOGEN LAMP
RED/WHT	FC	TAKEDOWN or FLASHER
BROWN	DF1 & PF1	SPLIT TAKEDOWN or SPLIT FLASHER
GRAY	DA	DRIVER ALLEY
YELLOW	PA	PASSENGER ALLEY

CONTROL WIRE FOR EXCLUSIVE OPTION

CONTROL WIRE ACTIVATED — **LAMP ACTIVATION**

BRN/WHT

- ☐ DUAL MODE – ACTIVATES STEADYBURN TAKEDOWN
- ☐ PRE2-1C PREEMPTION EMITTER in FC
- ☐ SEPARATELY ACTIVATE FRONT / CORNER STROBES – All ON
- ☐ FC – AUXILIARY DUAL OR SINGLE STROBE