930N-7208 FLASH PATTERN

LIGHTBAR LAMP CONFIGURATION

DF4 DF3 DF2 DF1 PF1 PF2 PF3 PF4
DC PC
DA PA
DR4 DR3 DR2 DR1 PR1 PR2 PR3 PR4

MODE	CONTROL WIRES ACTIVATED	LAMP OPERATION	
		REAR / ALLEY STROBES	FRONT / CORNER STROBES
1	ORG (REAR WIG-WAG)	DR2 ALTERNATES WITH PR2	NONE
2	ORG & BLU (360)	DR3, PR3 & DA SIMULTANEOUS AND ALTERNATE WITH DR2, PR2 & PA SIMULTANEOUS DR1 ALTERNATES WITH PR1	DF4 & PF4 SIMULTANEOUS AND ALTERNATE WITH DF3 & PF3 SIMULTANEOUS
3	ORG & BLU & WHT/BLK (360+)	SAME AS MODE 2	DF4 & PF4 SIMULTANEOUS AND ALTERNATE WITH DF3 & PF3 SIMULTANEOUS DC ALTERNATES WITH PC DF2 & PF2 SIMULTANEOUS AND ALTERNATE WITH DF1 & PF1 SIMULTANEOUS

CONTROL WIRES FOR OPTIONAL HALOGENS

CONTROL WIRE ACTIVATED		HALOGEN LAMP
RED/WHITE	PR4	REAR WORK or FLASHER
Or		
RED/WHITE	DR4/PR4	SPLIT REAR FLASHER
BROWN	DR4	REAR WORK or FLASHER
Or		
BROWN	DR4/PR4	SPLIT REAR WORK
GRAY	DA	DRIVER ALLEY
YELLOW	PA	PASSENGER ALLEY
BRN/WHT	DF1/PF1 or DF2/PF2	SPLIT TAKEDOWN or SPLIT FRONT FLASHER

CONTROL WIRES FOR OPTIONAL STOP / TURN / TAIL HALOGENS

CONTROL WIRE ACTIVATED		HALOGEN LAMP
RED/WHITE	DA	DRIVER ALLEY
BROWN	PA	PASSENGER ALLEY
GRAY	DR4	TURN SIGNAL
YELLOW	PR4	TURN SIGNAL
BRN/WHT	DR4 / PR4	TAIL LIGHT

NOTE: GREEN control wire activates high intensity to strobes.
Apply +12vdc to appropriate control wire to activate desired function.