930N-8009 FLASH PATTERN

LIGHTBAR LAMP CONFIGURATION

DF4 DF3 DF2 DF1 FC PF1 PF2 PF3 PF4
DC PC
DA PA
DR4 DR3 DR2 DR1 RC PR1 PR2 PR3 PR4

MODE	CONTROL WIRES ACTIVATED	LAMP OPERATION	
		REAR / ALLEY STROBES	FRONT / CORNER STROBES
0	NONE	NONE	NONE
ALL ON	ORG	DR3 & PR3 SIMULTANEOUS AND ALTERNATE WITH DR2 & PR2 SIMULTANEOUS DR1 ALTERNATES WITH PR1 DA ALTERNATES WITH PA DR4 ALTERNATES WITH PR4	DF3 & PF3 SIMULTANEOUS AND ALTERNATE WITH DF1 & PF1 SIMULTANEOUS DF2 ALTERNATES WITH PF2 DF4 ALTERNATES WITH PF4 DC ALTERNATES WITH PC FC SIMULTANEOUS
RIGHT ARROW	BLU	DR3, DR3 & DR2, DR2 & DR1, DR1 & PR1, PR1 & PR2, PR2 & PR3, PR3, DA & PA, REPEAT	DF3 & PF3 SIMULTANEOUS AND ALTERNATE WITH DF1 & PF1 SIMULTANEOUS DF2 ALTERNATES WITH PF2 DF4 ALTERNATES WITH PF4
LEFT ARROW	WHT/BLK	PR3, PR3 & PR2, PR2 & PR1, PR1 & DR1, DR1 & DR2, DR2 & DR3, DR3, DA & PA, REPEAT	SAME AS RIGHT ARROW
CENTER OUT	BLU & WHT/BLK	DR1 & PR1, DR2 & DR1 & PR1 & PR2, DR3 & DR2 & PR2 & PR3, DR3 & PR3, DA & PA, REPEAT	SAME AS RIGHT ARROW
RIGHT ARROW PLUS	ORG & BLU	DR3, DR3 & DR2, DR2 & DR1, DR1 & PR1, PR1 & PR2, PR2 & PR3, PR3, DA & PA, REPEAT DR4 ALTERNATES WITH PR4	SAME AS MODE 1
LEFT ARROW PLUS	ORG & WHT/BLK	PR3, PR3 & PR2, PR2 & PR1, PR1 & DR1, DR1 & DR2, DR2 & DR3, DR3, DA & PA, REPEAT DR4 ALTERNATES WITH PR4	SAME AS MODE 1
CENTER OUT PLUS	ORG & BLU & WHT/BLK	DR1 & PR1, DR2 & DR1 & PR1 & PR2, DR3 & DR2 & PR2 & PR3, DR3 & PR3, DA & PA, REPEAT DR4 ALTERNATES WITH PR4	SAME AS MODE 1

CONTROL WIRES FOR OPTIONAL HALOGENS

CONTROL WIRE ACTIVATED	HALOGEN LAMP	
GRAY	DA	(DRIVER ALLEY)
YELLOW	PA	(PASSENGER ALLEY)
RED/WHT	RC	(REAR WORK)
BRN/WHT	DR1/PR1	(FLASHER)
BRN	FC	(TAKEDOWN)

NOTE: GREEN control wire activates high intensity to strobes.
Apply +12vdc to appropriate control wire to activate desired function.