

465H-4004 FLASH PATTERN

LIGHTBAR LAMP CONFIGURATION

DF2L/DF2R
DF1L/DF1R
PF1L/PF1R
PF2L/PF2R
DC
PC

MODE	CONTROL WIRES ACTIVATED	LAMP OPERATION
		FRONT / CORNER STROBES
0	NONE	NONE
WARNING	ORG	DF1L, DF1R, PF2L & PF2R SIMULTANEOUS AND ALTERNATE WITH DF2L, DF2R, PF1L & PF1R SIMULTANEOUS
RIGHT ARROW	BLU	PF2R, PF2R & PF2L, PF2R & PF2L & PF1R, PF2R & PF2L & PF1R & PF1L, PF2R & PF2L & PF1R & PF1L & DF1R, PF2R & PF2L & PF1R & PF1L & DF1R & DF1L, PF2R & PF2L & PF1R & PF1L & DF1R & DF1L & DF2R, PF2R & PF2L & PF1R & PF1L & DF1R & DF1L & DF2R & DF2L, REPEAT
LEFT ARROW	WHT/BLK	DF2L, DF2L & DF2R, DF2L & DF2R & DF1L, DF2L & DF2R & DF1L & DF1R, DF2L & DF2R & DF1L & DF1R & PF1L, DF2L & DF2R & DF1L & DF1R & PF1L & PF1R, DF2L & DF2R & DF1L & DF1R & PF1L & PF1R & PF2L, DF2L & DF2R & DF1L & DF1R & PF1L & PF1R & PF2L & PF2R, REPEAT
CENTER OUT	BLU & WHT/BLK	DF1R & PF1L, DF1L & DF1R & PF1L & PF1R, DF2R & DF1L & DF1R & PF1L & PF1R & PF2L, DF2L & DF2R & DF1L & DF1R & PF1L & PF1R & PF2L & PF1R, REPEAT
SWEEP	ORG & WHT/BLK	PF2R & PF2L, PF1R & PF1L, DF1R & DF1L, DF2R & DF2L, DF1R & DF1L, PF1R & PF1L, REPEAT

CONTROL WIRES FOR OPTIONAL HALOGENS

CONTROL WIRE ACTIVATED
 RED/WHITE

HALOGEN LAMP
 DC & PC (CORNER FLASHER)

**NOTE: Apply +12vdc to appropriate control wire to activate desired function.
 Cut loop (22 AWG BLACK) on 930H-8A (halogen controller) to select low current arrow patterns.**