

# 930N-1701 FLASH PATTERN

## LIGHTBAR LAMP CONFIGURATION

FRONT

FC  
DC PC  
DA PA  
RC

MODE	CONTROL WIRES ACTIVATED	LAMP OPERATION	
		REAR / ALLEY STROBES	FRONT / CORNER STROBES
1	RED to +12 VDC BLK to GROUND	RC & PA SIMULTANEOUS AND ALTERNATE WITH DA (6 PULSES PER BURST)	DC ALTERNATES WITH PC (3 PULSES PER BURST) FC (6 PULSES PER BURST)

**NOTE: Optional GREEN control wire activates high intensity to strobes.  
Apply +12vdc to appropriate control wire to activate desired function.**