

930N-2402-0035 FLASH PATTERN

LIGHTBAR LAMP CONFIGURATION

DF1 PF1
 DC PC
 DA PA
 DR1 PR1

MODE	CONTROL WIRES ACTIVATED	LAMP OPERATION	
		REAR & ALLEY STROBES	FRONT STROBES
1	ORG & BLU	DR1 ALTERNATES WITH PR1 (6 PULSES PER BURST)	DF1 ALTERNATES WITH PF1 (6 PULSES PER BURST)
2	ORG & BLU & WHT/BLK	DR1 ALTERNATES WITH PR1 (6 PULSES PER BURST) DA ALTERNATES WITH PA (3 PULSES PER BURST)	SAME AS MODE 1

CONTROL WIRES FOR OPTIONAL HALOGENS

CONTROL WIRE ACTIVATED	HALOGEN LAMP	
BROWN	DC & PC	CORNER FLASHER
RED/WHITE	DR1 & PR1	SPLIT REARWORK or REAR FLASHER
GRAY	DA	DRIVER ALLEY
YELLOW	PA	PASSENGER ALLEY
BRN/WHITE	DF1 & PF1	SPLIT TAKEDOWN or FRONT FLASHER

**NOTE: GREEN control wire activates high intensity to strobes.
Apply +12vdc to appropriate control wire to activate desired function.**