

930N-3203-0007 FLASH PATTERN

LIGHTBAR LAMP CONFIGURATION

DF1 FC PF1
 DC PC
 DA PA
 DR1 RC PR1

MODE	CONTROL WIRES ACTIVATED	STROBE LAMP OPERATION
1	ORG	DC ALTERNATES WITH PC (4 PULSES PER BURST)
2	ORG & BLU	DF1 ALTERNATES WITH PF1 (6 PULSES PER BURST) DR1 ALTERNATES WITH PR1 (6 PULSES PER BURST) DC ALTERNATES WITH PC (3 PULSES PER BURST)
3	ORG & BLU & WHT/BLK	SAME AS MODE 2

CONTROL WIRES FOR STANDARD HALOGEN FLASHERS

CONTROL WIRE ACTIVATED	HALOGEN LAMP	
RED/WHT	RC	REAR FLASHER
YEL	DA & PA	ALLEY FLASHER
OR OPTIONAL SOLID STEADYBURN ALLEY		
YEL	PA	ALLEY LIGHT
GRY	DA	ALLEY LIGHT

CONTROL WIRES FOR OPTIONAL HALOGENS

CONTROL WIRE ACTIVATED	HALOGEN LAMP	
BROWN	FC	TAKEDOWN
OR OPTIONAL DUAL MODE		
BROWN	FC	FLASHER
BRN/WHT	FC	TAKEDOWN

**NOTE: GREEN control wire activates high intensity to strobes.
Apply +12vdc to appropriate control wire to activate desired function.**