

930N-3203-0115 FLASH PATTERN

LIGHTBAR LAMP CONFIGURATION

DF1 FC PF1
DC PC
DA PA
DR1 RC PR1

CONTROL WIRES ACTIVATED	STROBE LAMP OPERATION
"ALL-ON"	DF1 ALTERNATES WITH PF1 (6 PULSES PER BURST) DR1 ALTERNATES WITH PR1 (6 PULSES PER BURST) DC ALTERNATES WITH PC (3 PULSES PER BURST)

NOTE: Apply +12vdc to power cable to activate strobe lamps in high intensity.