

# 930N-5606-0018 FLASH PATTERN

## LIGHTBAR LAMP CONFIGURATION

	DF3	DF2	DF1	PF1	PF2	PF3	
DC							PC
DA							PA
	DR3	DR2	DR1	PR1	PR2	PR3	

MODE	CONTROL WIRES ACTIVATED	LAMP OPERATION	
		REAR / ALLEY STROBES	FRONT / CORNER STROBES
0	NONE	NONE	NONE
1	ORG	DR2 ALTERNATES WITH PR2	DF2 ALTERNATES WITH PF2
2	BLU	DR3 & PA SIMULTANEOUS AND ALTERNATE WITH PR3 & DA SIMULTANEOUS (4 PULSES PER BURST)	DF3 & PC SIMULTANEOUS AND ALTERNATE WITH PF3 & DC SIMULTANEOUS (4 PULSES PER BURST)
3	ORG & BLU	DR3 & PR3 SIMULTANEOUS AND ALTERNATE WITH DR2 & PR2 SIMULTANEOUS (6 PULSES PER BURST) DA ALTERNATES WITH PA (3 PULSES PER BURST)	DF3 & PF3 SIMULTANEOUS AND ALTERNATE WITH DF2 & PF2 SIMULTANEOUS (6 PULSES PER BURST) DC ALTERNATES WITH PC (3 PULSES PER BURST)

## CONTROL WIRES FOR OPTIONAL HALOGENS

CONTROL WIRE ACTIVATED	HALOGEN LAMP
RED/WHITE	PF1 (TAKEDOWN)
BROWN	DF1 (TAKEDOWN)
BROWN/WHITE	PR1 (REAR WORK)
GRAY	DR1 (REAR WORK)
YELLOW	DA & PA (ALLEY LAMPS)

**NOTE: GREEN control wire activates high intensity to strobes.  
Apply +12vdc to appropriate control wire to activate desired function.**