

930N-5606-0047 FLASH PATTERN

LIGHTBAR LAMP CONFIGURATION

DF3	DF2	DF1	PF1	PF2	PF3
DC					PC
DA					PA
DR3	DR2	DR1	PR1	PR2	PR3

MODE	CONTROL WIRES ACTIVATED	LAMP OPERATION
		FRONT / CORNER REAR / ALLEY STROBES
1	ORG	DR3 & PR3 SIMULTANEOUS AND ALTERNATE WITH DF3 & PF3 SIMULTANEOUS (6 PULSES PER BURST) DC ALTERNATES WITH PC (3 PULSES PER BURST) DA ALTERNATES WITH PA (3 PULSES PER BURST)

CONTROL WIRES FOR OPTIONAL HALOGENS

CONTROL WIRE ACTIVATED	HALOGEN LAMP	
BROWN	DR1	WORK LIGHT
RED/WHITE	PR1	WORK LIGHT
BROWN/WHITE	DR2 & PR2	TAIL LIGHTS
GRAY	DR2	TURN SIGNAL
YELLOW	PR2	TURN SIGNAL
BLUE	DF2 & PF2	FLASHER

**NOTE: GREEN control wire activates high intensity to strobes.
Apply +12vdc to appropriate control wire to activate desired function.**