

# 930N-5606-0058 FLASH PATTERN

## LIGHTBAR LAMP CONFIGURATION

DF3	DF2	DF1	PF1	PF2	PF3
DC					PC
DA					PA
DR3	DR2	DR1	PR1	PR2	PR3

MODE	CONTROL WIRES ACTIVATED	LAMP OPERATION	
		REAR / ALLEY STROBES	FRONT / CORNER STROBES
0	NONE	NONE	NONE
1	ORG	DR2 ALTERNATES WITH PR2	NONE
2	ORG & BLU	DR3, PR3 & DA SIMULTANEOUS AND ALTERNATE WITH DR2, PR2 & PA SIMULTANEOUS	DF2 & PF2 SIMULTANEOUS AND ALTERNATE WITH DF3 & PF3 SIMULTANEOUS
3	ORG & BLU & WHT/BLK	DR3, PR3 & DA SIMULTANEOUS AND ALTERNATE WITH DR2, PR2 & PA SIMULTANEOUS	DF2 & PF2 SIMULTANEOUS AND ALTERNATE WITH DF3 & PF3 SIMULTANEOUS DC ALTERNATES WITH PC

## CONTROL WIRES FOR OPTIONAL HALOGENS

### CONTROL WIRE ACTIVATED

RED/WHITE  
BROWN  
BROWN/WHITE  
GRAY  
YELLOW

### HALOGEN LAMP

PF1 (TAKEDOWN)  
DF1 (TAKEDOWN)  
PR1 (REAR WORK)  
DR1 (REAR WORK)  
DA & PA (ALLEY LAMPS)

**NOTE: GREEN control wire activates high intensity to strobes.  
Apply +12vdc to appropriate control wire to activate desired function.**