

930N-5606-0072 FLASH PATTERN

LIGHTBAR LAMP CONFIGURATION

DF3	DF2	DF1	PF1	PF2	PF3
DC					PC
DA					PA
DR3	DR2	DR1	PR1	PR2	PR3

MODE	CONTROL WIRES ACTIVATED	LAMP OPERATION	
		REAR / ALLEY STROBES	FRONT / CORNER STROBES
0	NONE	NONE	NONE
1	ORG (ALL STROBES)	DA ALTERNATES WITH PA DR3 ALTERNATES WITH PR3	DF3 & PF3 SIMULTANEOUS AND ALTERNATE WITH DF2 & PF2 SIMULTANEOUS DF1 ALTERNATES WITH PF1 DC ALTERNATES WITH PC

CONTROL WIRES FOR OPTIONAL HALOGENS

CONTROL WIRE ACTIVATED

BROWN
GRAY
YELLOW

HALOGEN LAMP

DF1 & PF1 (TAKEDOWN)
DA (DRIVER ALLEY)
PA (PASSENGER ALLEY)

NOTE: GREEN control wire activates high intensity to strobes.
Apply +12vdc to appropriate control wire to activate desired function.