

930N-7208-0069 FLASH PATTERN

LIGHTBAR LAMP CONFIGURATION

DF4	DF3	DF2	DF1	PF1	PF2	PF3	PF4
DC							PC
DA							PA
DR4	DR3	DR2	DR1	PR1	PR2	PR3	PR4

MODE	CONTROL WIRES ACTIVATED	LAMP OPERATION	
		REAR / ALLEY STROBES	FRONT / CORNER STROBES
1	ORG (ALL STROBES)	DR3 & PR3 SIMULTANEOUS AND ALTERNATE WITH DR2 & PR2 SIMULTANEOUS (6 PULSES PER BURST) DR1 ALTERNATES WITH PR1 DR4 ALTERNATES WITH PR4 (3 PULSES PER BURST) DA ALTERNATES WITH PA (5 PULSES PER BURST)	DF4 & PF4 SIMULTANEOUS AND ALTERNATE WITH DF3 & PF3 SIMULTANEOUS (6 PULSES PER BURST) DF2 ALTERNATES WITH PF2 DC ALTERNATES WITH PC (3 PULSES PER BURST)
2	ORG & BLU (RIGHT ARROW PLUS)	DR3, DR3 & DR2, DR2 & DR1, DR1 & PR1, PR1 & PR2, PR2 & PR3, PR3, DR4 & PR4, REPEAT DA ALTERNATES WITH PA (5 PULSES PER BURST)	SAME AS MODE 1
3	ORG & WHT/BLK (LEFT ARROW PLUS)	PR3, PR3 & PR2, PR2 & PR1, PR1 & DR1, DR1 & DR2, DR2 & DR3, DR3, DR4 & PR4, REPEAT DA ALTERNATES WITH PA (5 PULSES PER BURST)	SAME AS MODE 1
4	ORG & BLU & WHT/BLK (CENTER OUT PLUS)	DR1 & PR1, DR2 & DR1 & PR1 & PR2, DR3 & DR2 & PR2 & PR3, DR3 & PR3, DR4 & PR4 REPEAT DA ALTERNATES WITH PA (5 PULSES PER BURST)	SAME AS MODE 1
5	BLU (RIGHT ARROW)	SAME AS MODE 2 (EXCEPT DA & PA DISABLED)	NONE
6	WHT/BLK (LEFT ARROW)	SAME AS MODE 3 (EXCEPT DA & PA DISABLED)	NONE
7	BLU & WHT/BLK (CENTER OUT)	SAME AS MODE 4 (EXCEPT DA & PA DISABLED)	NONE

NOTE: FACTORY DEFAULT – HIGH INTENSITY
GROUNDING the GREEN control wire activates low intensity to strobes.
Apply +12vdc to all other control wires to activate desired function.
For operation with a Tomar 940N-DCP or 940N-SIREN, use Profile N2.

CONTROL WIRES FOR OPTIONAL HALOGENS

CONTROL WIRE ACTIVATED	HALOGEN LAMP	
RED/WHITE	PF1	TAKEDOWN
BROWN	DF1	TAKEDOWN
GRAY	DA	DRIVER ALLEY
YELLOW	PA	PASSENGER ALLEY