

930N-9611-0046 FLASH PATTERN

LIGHTBAR LAMP CONFIGURATION

| | | | | | | | | | | | |
|----|-----|-----|-----|-----|-----|----|-----|-----|-----|-----|-----|
| | DF5 | DF4 | DF3 | DF2 | DF1 | FC | PF1 | PF2 | PF3 | PF4 | PF5 |
| | DC | | | | | | | | | | PC |
| DA | | | | | | | | | | | PA |
| | DR5 | DR4 | DR3 | DR2 | DR1 | RC | PR1 | PR2 | PR3 | PR4 | PR5 |

| MODE | CONTROL WIRES ACTIVATED | LAMP OPERATION | |
|------|-------------------------|--|--|
| | | REAR / ALLEY STROBES | FRONT / CORNER STROBES |
| 1 | ORG | DR5 & PR5 SIMULTANEOUS AND ALTERNATE WITH DR3 & PR3 SIMULTANEOUS (6 PULSES PER BURST) RC - (3 PULSES PER BURST) DA ALTERNATES WITH PA (3 PULSES PER BURST) | DF5 & PF5 SIMULTANEOUS AND ALTERNATE WITH DF3 & PF3 SIMULTANEOUS (6 PULSES PER BURST) FC - (3 PULSES PER BURST) DC ALTERNATES WITH PC (3 PULSES PER BURST) |

CONTROL WIRES FOR OPTIONAL HALOGENS

CONTROL WIRE ACTIVATED

BROWN
RED/WHITE

HALOGEN LAMP

DF4 & PF4 FRONT FLASHER
DR4 & PR4 REAR FLASHER

ADDITIONAL CONTROL WIRES FOR OPTIONAL DUAL MODE HALOGENS

To be used with the above Front Flasher and or Rear Flasher Option

CONTROL WIRE ACTIVATED

YEL or (BROWN & YEL)
GRY or (RED/WHT & GRY)

FLASHER HALOGEN LAMP

DF4 & PF4 STEADYBURN
DR4 & PR4 STEADYBURN

**NOTE: GREEN control wire activates high intensity to strobes.
Apply +12vdc to appropriate control wire to activate desired function.**