

930N1-3203-0045 FLASH PATTERN

LIGHTBAR LAMP CONFIGURATION

DF1 FC PF1
DC PC
DA PA
DR1 RC PR1

MODE	CONTROL WIRES ACTIVATED	LAMP OPERATION FRONT / CORNER / ALLEY STROBES
0	NONE	NONE
1	ORANGE	PF1 & DF1 SIMULTANEOUS AND ALTERNATE WITH PA & DA SIMULTANEOUS (6 PULSES PER BURST) PC ALTERNATES WITH DC (3 PULSES PER BURST) FC (3 PULSES PER BURST)

CONTROL WIRES FOR OPTIONAL HALOGEN LAMPS

CONTROL WIRE ACTIVATED

BLUE
WHT/BLK

HALOGEN LAMP

PA (PASSENGER ALLEY)
DA (DRIVER ALLEY)

**NOTE: GREEN control wire activates high intensity to strobes.
Apply +12vdc to appropriate control wire to activate desired function.**