

# 930N1-6407 FLASH PATTERN

## LIGHTBAR LAMP CONFIGURATION

DF3	DF2	DF1	FC	PF1	PF2	PF3
DC						PC
DA						PA
DR3	DR2	DR1	RC	PR1	PR2	PR3

MODE	CONTROL WIRES ACTIVATED	LAMP OPERATION
		FRONT / CORNER / ALLEY STROBES
0	NONE	NONE
1	ORG	DF1 & PA SIMULTANEOUS AND ALTERNATE WITH PF1 & DA SIMULTANEOUS (6 PULSES PER BURST) DC ALTERNATES WITH PC (3 PULSES PER BURST)
2	BLU	DF3, DF1, PF2 & PA SIMULTANEOUS AND ALTERNATE WITH PF3, PF1, DF2 & DA SIMULTANEOUS (6 PULSES PER BURST) DC ALTERNATES WITH PC (3 PULSES PER BURST)
3	ORG & BLU	SAME AS MODE 2

## CONTROL WIRES FOR OPTIONAL HALOGENS

CONTROL WIRE	HALOGEN LAMP	
BROWN	FC or DF1 & PF1	(TAKEDOWN or SPLIT TAKEDOWN)
GRAY	DA	(DRIVER ALLEY)
YELLOW	PA	(PASSENGER ALLEY)

## CONTROL WIRE FOR PRE2-1C Preemption Emitter

BRN/WHT	STROBE LAMP ACTIVATED FC - PREEMPTION EMITTER
---------	--

**NOTE: GREEN control wire activates high intensity to strobes.  
Apply +12vdc to appropriate control wire to activate desired function.**