

930N1-8810 FLASH PATTERN

LIGHTBAR LAMP CONFIGURATION

DF5	DF4	DF3	DF2	DF1	PF1	PF2	PF3	PF4	PF5
DC									PC
DA									PA
DR5	DR4	DR3	DR2	DR1	PR1	PR2	PR3	PR4	PR5

MODE	CONTROL WIRES ACTIVATED	LAMP OPERATION FRONT / CORNER / ALLEY STROBES
1	ORG	DF1 & PF1 SIMULTANEOUS AND ALTERNATE WITH DF3 & PF3 SIMULTANEOUS (6 PULSES) DF2 ALTERNATES WITH PF2 (3 PULSES) DF4 ALTERNATES WITH PF4 (3 PULSES)
2	ORG & BLU	DF1 & PF1 SIMULTANEOUS AND ALTERNATE WITH DF3 & PF3 SIMULTANEOUS (6 PULSES) DF2 ALTERNATES WITH PF2 (3 PULSES) DF4 ALTERNATES WITH PF4 (3 PULSES) DA & PA SIMULTANEOUS AND ALTERNATE WITH DF5 & PF5 SIMULTANEOUS (6 PULSES) DC ALTERNATES WITH PC (3 PULSES)

CONTROL WIRES FOR OPTIONAL HALOGEN LAMPS

CONTROL WIRE ACTIVATED	HALOGEN LAMP
BROWN	DF1 & PF1 (SPLIT TAKEDOWN)
GRAY	DA (DRIVER ALLEY)
YELLOW	PA (PASSENGER ALLEY)

NOTE:

1. **GREEN** control wire activates high intensity to strobes. Apply +12vdc to appropriate control wire to activate desired function.