

930NH-4805-0070 FLASH PATTERN

LIGHTBAR LAMP CONFIGURATION

	DF2	DF1L/DF1R	FCL/FCR	PF1L/PF1R	PF2	
DC						PC
DA						PA
	DR2	DR1L/DR1R	RCL/RCR	PR1L/PR1R	PR2	

MODE	CONTROL WIRES ACTIVATED	LAMP OPERATION	
		REAR / ALLEY STROBES & HALOGENS	FRONT / CORNER STROBES & HALOGENS
0	NONE	NONE	NONE
1	ORG	DR1 ALTERNATES WITH PR1 RCL ALTERNATES WITH RCR	NONE
2	ORG & BLU	DR2, DR1 & PA SIMULTANEOUS AND ALTERNATE WITH PR2, PR1 & DA SIMULTANEOUS RCL ALTERNATE WITH RCR	DF1R & FCR SIMULTANEOUS AND ALTERNATE WITH PF1L & FCL SIMULTANEOUS
3	ORG & BLU & WHT/BLK	SAME AS MODE 2	DF2, PC, DF1R & FCR SIMULTANEOUS AND ALTERNATE WITH PF2, DC, PF1L & FCL SIMULTANEOUS

CONTROL WIRES FOR OPTIONAL HALOGENS

CONTROL WIRE ACTIVATED	HALOGEN LAMP
BROWN	DF1L & PF1R (TAKEDOWN)
GRAY	DA (DRIVER ALLEY)
YELLOW	PA (PASSENGER ALLEY)

**NOTE: GREEN control wire activates high intensity to strobes.
Apply +12vdc to appropriate control wire to activate desired function.**