

950N-4805 NEOBE LIGHTBAR
0034 - FACTORY SET FLASH PATTERN

Progressive Slide Switch application

Mode 1

+12 vdc **ORANGE** Control Wire Activated

Front & Corner Warning Lamps: *Inboard/Outboard without Corner - 6 pulse Neobe*

Rear & End Warning Lamps: *Left/Right with End - 6 pulse Neobe*

Mode 2

+12 vdc **ORANGE & BLUE** Control Wires Activated

Front & Corner Warning Lamps: *Inboard/Outboard with Corner - 6 pulse Neobe*

Rear & End Warning Lamps: *Left/Right with End - 6 pulse Neobe*

Mode 3

+12 vdc **ORANGE, BLUE & WHITE/BLACK** Control Wires Activated

Front & Corner Warning Lamps: *Inboard/Outboard without Corner - 6 pulse Neobe*

Rear & End Warning Lamps: *Left/Right with End - 6 pulse Neobe*

Any other combinations of the ORG, BLUE and WHITE/BLACK control wires = Mode 2.

See 950N-4805 Appendix A for additional 950N-4805 Control & Power Wire functions.

NOTE: The 0034 configuration can be order with an optional DR1 / PR1 Halogen Flasher, activated by WHT wire Rearwork.