

930NH1-4805 FLASH PATTERN

LIGHTBAR LAMP CONFIGURATION

DF2	DF1	FCL/FCR	PF1	PF2
DC				PC
DA				PA
DR2	DR1	RC	PR1	PR2

MODE	CONTROL WIRES ACTIVATED	LAMP OPERATION	
		FRONT / CORNER / ALLEY STROBES & HALOGENS	OPTIONAL STROBES & HALOGENS
0	NONE	NONE	
1	ORG (STROBES ONLY)	DF2 & PA SIMULTANEOUS AND ALTERNATE WITH PF2 & DA SIMULTANEOUS DC ALTERNATES WITH PC	FCL ALTERNATES WITH FCR (Optional Strobe/Strobe in FC)
2	ORG & BLU (HALOGENS ONLY)	DF1 ALTERNATES WITH PF1	PA ALTERNATES WITH DA (Optional Alley Flasher)
3	ORG & BLU & WHT/BLK (STROBES & HALOGENS)	DF2 & DF1 SIMULTANEOUS ALTERNATES WITH PF2 & PF1 SIMULTANEOUS DC ALTERNATES WITH PC	FCL ALTERNATES WITH FCR (Optional Strobe/Strobe in FC) PA ALTERNATES WITH DA (Optional Alley Flasher)

CONTROL WIRES FOR OPTIONAL HALOGENS

CONTROL WIRE ACTIVATED	HALOGEN LAMP
GRAY	DA (STEADYBURN DRIVER ALLEY)
YELLOW	PA (STEADYBURN PASSENGER ALLEY)
BROWN	FC (TAKEDOWN or FRONT FLASHER)

CONTROL WIRE FOR ADDITIONAL OPTIONS

CONTROL WIRE ACTIVATES BRN/WHITE
 930-PRE2-1C Preemption Emitter or Dual Mode Takedown (Activates Steadyburn)

NOTE: GREEN control wire activates high intensity to strobes.
Apply +12vdc to appropriate control wire to activate desired function.