

930NH-4805-0003 FLASH PATTERN

LIGHTBAR LAMP CONFIGURATION

DF2
DF1
FC
PF1
PF2

DC
PC

DA
PA

DR2L/DR2R
DR1L/DR1R
RCL/RCR
PR1L/PR1R
PR2L/PR2R

MODE	CONTROL WIRES ACTIVATED	LAMP OPERATION	
		REAR / ALLEY STROBES & HALOGENS	FRONT / CORNER STROBES
0	NONE	NONE	NONE
1	ORG	DA ALTERNATES WITH PA	DF2 ALTERNATES WITH PF2
2	BLU	DR1L ALTERNATES WITH PR1R	DF1 ALTERNATES WITH PF1 DC ALTERNATES WITH PC
3	ORG & BLU	DR1L ALTERNATES WITH PR1R DA ALTERNATES WITH PA	DF2 & DF1 SIMULTANEOUS AND ALTERNATE WITH PF2 & PF1 SIMULTANEOUS DC ALTERNATES WITH PC
WARNING	RED/WHT	DR2L, DR2R, RCR & PR1L SIMULTANEOUS AND ALTERNATE WITH DR1R, RCL, PR2L & PR2R SIMULTANEOUS	NONE
RIGHT ARROW	BRN/WHT	DR2L, DR2L & DR2R, DR2L & DR2R & DR1R, DR2L & DR2R & DR1R & RCL, DR2L & DR2R & DR1R & RCL & RCR, DR2L & DR2R & DR1R & RCL & RCR & PR1L, DR2L & DR2R & DR1R & RCL & RCR & PR1L & PR2L, DR2L & DR2R & DR1R & RCL & RCR & PR1L & PR2L & PR2R, REPEAT	NONE
LEFT ARROW	WHT/BLK	PR2R, PR2R & PR2L, PR2R & PR2L & PR1L, PR2R & PR2L & PR1L & RCR, PR2R & PR2L & PR1L & RCR & RCL, PR2R & PR2L & PR1L & RCR & RCL & DR1R, PR2R & PR2L & PR1L & RCR & RCL & DR1R & DR2R, PR2R & PR2L & PR1L & RCR & RCL & DR1R & DR2R & DR2L, REPEAT	NONE
CENTER OUT	BRN/WHT & WHT/BLK	RCL & RCR, DR1R & RCL & RCR & PR1L, DR2R & DR1R & RCL & RCR & PR1L & PR2L, DR2L & DR2R & DR1R & RCL & RCR & PR1L & PR2L & PR2R, REPEAT	NONE
SWEEP	RED/WHT & WHT/BLK	DR2L & DR2R, DR1R & RCL, RCR & PR1L, PR2L & PR2R, RCR & PR1L, DR1R & RCL, REPEAT	NONE

CONTROL WIRES FOR OPTIONAL HALOGENS

CONTROL WIRE ACTIVATED

BROWN
 GRAY
 YELLOW

HALOGEN LAMP

FC (TAKEDOWN)
 DA (DRIVER ALLEY)
 PA (PASSENGER ALLEY)

NOTE: GREEN control wire activates high intensity to strobes.

Apply +12vdc to appropriate control wire to activate desired function.

Cut loop (22 AWG BLACK) on 930H-8A (halogen controller) to select low current arrow patterns.