

930NH-4805-0061 FLASH PATTERN

LIGHTBAR LAMP CONFIGURATION

DF2	DF1L/DF1R	FC	PF1L/PF1R	PF2
DC				PC
DA				PA
DR2L/DR2R	DR1L/DR1R	RCL/RCR	PR1L/PR1R	PR2L/PR2R

MODE	CONTROL WIRES ACTIVATED	LAMP OPERATION	
		REAR / ALLEY STROBES & HALOGENS	FRONT / CORNER STROBES & HALOGENS
0	NONE	NONE	NONE
1	ORG	DR2R AND ALTERNATE WITH PR2L	NONE
2	ORG & BLU	DR2R AND ALTERNATE WITH PR2L DR2L AND ALTERNATE WITH PR2R DA ALTERNATES WITH PA	DF2 ALTERNATES WITH PF2 DC ALTERNATES WITH PC

CONTROL WIRES FOR OPTIONAL HALOGENS

CONTROL WIRE ACTIVATED	HALOGEN LAMP
BROWN	FC (TAKEDOWN)
GRAY	DA (DRIVER ALLEY)
YELLOW	PA (PASSENGER ALLEY)
BROWN/WHITE	DF1R & PF1L (STEADY)
RED/WHITE	DF1L & PF1R (FLASHER)

NOTE: GREEN control wire activates high intensity to strobes.
Apply +12vdc to appropriate control wire to activate desired function.

CONTROL WIRES FOR CUSTOMER CONTROLLED HALOGEN ARROW

TOMAR M1072 CABLE	HALOGEN LAMP
YELLOW	DR1L
YELLOW/WHITE	DR1R
RED	RCL
RED/WHITE	RCR
BLACK	PR1L
BLACK/WHITE	PR1R

Apply -12vdc to appropriate control wire to activate desired function.