

465NH-6407-0094 FLASH PATTERN

LIGHTBAR LAMP CONFIGURATION

DC DF3 DF2 DF1 FC PF1 PF2 PF3 PC

MODE	CONTROL WIRES ACTIVATED	LAMP OPERATION
		FRONT / CORNER STROBES
1	ORG	DF3, DF1 & PC SIMULTANEOUS AND ALTERNATE WITH PF3, PF1 & DC SIMULTANEOUS

OPTIONAL HALOGEN CONTROL WIRES

CONTROL WIRE ACTIVATED	OPERATION
BROWN	PF2 TAKEDOWN
BROWN	OR PF2 & DF2 FLASHER
YEL	FC TAKEDOWN or FLASHER
GRY	DF2 TAKEDOWN
BRN/WHT	DUAL MODE – STEADYBURN ACTIVATION APPLY TO FC and or DF2 & PF2. IF APPLIED TO BOTH – THE STEADYBURN ACTIVATION WILL BE SIMULTANEOUS

**NOTE: GREEN control wire activates high intensity to strobes.
Apply +12vdc to appropriate control wire to activate desired function.**