

465NH-8009-0112 FLASH PATTERN

LIGHTBAR LAMP CONFIGURATION

DF4	DF3	DF2	DF1	FC	PF1	PF2	PF3	PF4
DC								PC

CONTROL WIRES FOR HALOGEN LAMPS

GRY	DF4
BLUE	DF3
WHT/BLK	DF2 & PF2
ORANGE	DF1
BRN	FC
BRN/WHT	PF1
YEL	PF3
RED/WHT	PF4

CONTROL WIRE FOR STROBE LAMPS

GRN	DC ALTERNATES WITH PC
-----	-----------------------

NOTE: Apply +12vdc to the appropriate control wire to activate desired lamp.