

465NH-7208-0119 FLASH PATTERN

LIGHTBAR LAMP CONFIGURATION

DF4 DF3 DF2 DF1 PF1 PF2 PF3 PF4
DC PC

MODE	CONTROL WIRES ACTIVATED	LAMP OPERATION
		FRONT / CORNER STROBES
1	ORG	DF4 ALTERNATES WITH PF4 (4 PULSES PER BURST)
2	BLU or ORG & BLU	DF4, DF3, & DF1 SIMULTANEOUS AND ALTERNATE WITH PF4, PF3, & PF1 SIMULTANEOUS (6 PULSES PER BURST)

CONTROL WIRES FOR STANDARD HALOGEN LAMPS

CONTROL WIRE ACTIVATED	OPERATION
GRY	DF2
YEL	PF2
BRN	DC & PC

CONTROL WIRES FOR OPTIONAL PRE2-1C

CONTROL WIRE ACTIVATED	DF1 STROBE LAMP
RED/WHT	ACTIVATE PREEMPTION EMITTER

CONTROL WIRES FOR OPTIONAL ICC MARKER LIGHTS

CONTROL WIRE ACTIVATED	
BRN/WHT	ACTIVATE ICC MARKER LIGHTS

**NOTE: GREEN control wire activates high intensity to strobes.
Apply +12vdc to appropriate control wire to activate desired function.**