

**950N-6407 NEOBE LIGHTBAR**  
0000 - FACTORY SETTING FLASH PATTERN

Progressive Slide Switch application

**Mode 1**

+12 vdc **ORANGE**: Control Wire Activated

Front & Corner Warning Lamps: *Off*

Rear & Side Warning Lamps: *Inboard/Outboard with Sides - 6 pulse Neobe*

**Mode 2**

+12 vdc **ORANGE** & **BLUE** Control Wires Activated

Front & Corner Warning Lamps: *Inboard/Outboard without Corner - 6 pulse Neobe*

Rear & Side Warning Lamps: *Off*

**Mode 3**

+12 vdc **ORANGE**, **BLUE** & **WHITE/BLACK** Control Wires Activated

Front & Corner Warning Lamps: *Inboard/Outboard with Corner - 6 pulse Neobe*

Rear & Side Warning Lamps: *Inboard/Outboard with Sides - 6 pulse Neobe*

**Traffic Directional Modes on Rear Lamps - Left, Right or Center Out - 6 pulse Neobe**

Front Warning Lamps: *Inboard/Outboard without Corner - 6 pulse Neobe*

**Any other combinations of the ORG, BLUE and WHITE/BLACK control wires = OFF.**

**See 950N-6407 Appendix A for additional 950N-6407 Control & Power Wire functions.**