

950N-8810 NEOBE LIGHTBAR
0039 - FACTORY SETTING FLASH PATTERN

Progressive Slide Switch application

Mode 1

+12 vdc **ORANGE** Control Wire Activated

Front Warning Lamps: *Alternating - 6 pulse Neobe*
Rear Warning Lamps: *Off*
Side Warning Lamps: *Front Outboard w/ Side & Corner - 6 pulse Neobe*

Mode 2

+12 vdc **ORANGE & BLUE** Control Wires Activated

Front Warning Lamps: *Off*
Rear Warning Lamps: *Alternating - 6 pulse Neobe*
Side Warning Lamps: *Off*

Mode 3

+12 vdc **ORANGE, BLUE & WHITE/BLACK** Control Wires Activated

Front Warning Lamps: *Alternating - 6 pulse Neobe*
Rear Warning Lamps: *Alternating - 6 pulse Neobe*
Side Warning Lamps: *Front Outboard w/ Side & Corner - 6 pulse Neobe*

Traffic Directional Modes (8 Element) - Left, Right or Center Out - 6 pulse Neobe

Front Warning Lamps: *Off*
Side Warning Lamps: *Off*

Any other combinations of the ORG, BLUE and WHITE/BLACK control wires = OFF.

See 950N-8810 Appendix A for additional 950N-8810 Control & Power Wire functions.