465N-4805 FLASH PATTERN

LIGHTBAR LAMP CONFIGURATION

DF2 DF1 FC PF1 PF2
DC PC

MODE	CONTROL WIRES ACTIVATED	LAMP OPERATION
		FRONT / CORNER STROBES
1	ORG	NONE
2	ORG & BLU	DF1 & PF1 SIMULTANEOUS AND ALTERNATE WITH DF2 & PF2 SIMULTANEOUS
3	ORG & BLU & WHT/BLK With OPTIONAL PRE *PREEMPTION SIGNAL EMITTED	DF1 & PF1 SIMULTANEOUS AND ALTERNATE WITH DF2 & PF2 SIMULTANEOUS (6 PULSES PER BURST) DC ALTERNATES WITH PC (3 PULSES PER BURST)
4	ORG & WHT/BLK	SAME AS MODE 3

*** PREEMPTION OPTION:**
The WHITE/BROWN control wire activates the PARKING BRAKE OVERRIDE, deactivating the PREEMPTION signal when in Mode 3 (PREEMPTION). The flash pattern will not change, but the flash frequency will revert to the standard flash rates of Modes 1, 2 & 4.

CONTROL WIRES FOR OPTIONAL HALOGENS

CONTROL WIRE ACTIVATED	HALOGEN LAMP
BRN	FC (TAKEDOWN)

NOTE: GREEN control wire activates high intensity to strobes.
Apply +12vdc to appropriate control wire to activate desired function.