465N-8009-0087 FLASH PATTERN

LIGHTBAR LAMP CONFIGURATION

DF4 DF3 DF2 DF1 FC PF1 PF2 PF3 PF4
DC PC

MODE	CONTROL WIRES ACTIVATED	LAMP OPERATION
		FRONT / CORNER STROBES
0	NONE	NONE
1	ORG	DF4 & PF4 SIMULTANEOUS AND ALTERNATE WITH DF3 & PF3 SIMULTANEOUS (6 PULSES PER BURST) DF1 ALTERNATES WITH PF1 (3 PULSES PER BURST) DC ALTERNATES WITH PC (3 PULSES PER BURST)
2	ORG & BLU	SAME AS MODE 1
3	ORG & WHT/BLK	SAME AS MODE 1
4	ORG & BLU & WHT/BLK (**OPTIONAL PREEMPTION**)	SAME FLASH PATTERN AS MODE 1 NOTE: EXCEPT LAMPS DF4, DF3, PF3 & PF4 OPERATE IN **PREEMPTION** FLASH RATE, IF THE PRE OPTION IS ORDERED AND FACTORY INSTALLED

* NOTE: PREEMPTION CAN BE ACHIEVED WITH EITHER OPTION /PRE OR /PRE2-1C

CONTROL WIRES FOR SCENE LIGHT HALOGENS

CONTROL WIRE ACTIVATED	HALOGEN LAMP
GRY	DF2 (SCENE LIGHT)
YEL	PF2 (SCENE LIGHT)

CONTROL WIRES FOR OPTIONAL HALOGEN

CONTROL WIRE ACTIVATED	HALOGEN LAMP
RED/WHT	FC (TAKEDOWN OR SPLIT TD)

CONTROL WIRES FOR OPTIONAL PREEMPTION

CONTROL WIRE ACTIVATED	STROBE LAMPS
BRN	PARKING BRAKE OVERRIDE

CONTROL WIRES FOR OPTIONAL PRE2-1C

CONTROL WIRE ACTIVATED	FC STROBE LAMP
BRN	ACTIVATE PREEMPTION EMITTER

CONTROL WIRES FOR OPTIONAL ICC MARKER LIGHTS

CONTROL WIRE ACTIVATED	
BRN/WHT	ACTIVATE ICC MARKER LIGHTS

NOTE: GREEN control wire activates high intensity to strobes.
Apply +12vdc to appropriate control wire to activate desired function.