930N-4004-0090 FLASH PATTERN

LIGHTBAR LAMP CONFIGURATION

DF2 DF1 PF1 PF2
DC PC
DA PA
DR2 DR1 PR1 PR2

MODE	CONTROL WIRES ACTIVATED	LAMP OPERATION	
		INBOARD, CORNERS & ALLEYS STROBES	OUTBOARD STROBES
0	NONE	NONE	NONE
1	BRN/WHT	NONE	DF2 ALTERNATES WITH PF2 DR2 ALTERNATES WITH PR2
2	ORG	DF1 ALTERNATES WITH PF1 DR1 ALTERNATES WITH PR1 DC ALTERNATES WITH PC DA ALTERNATES WITH PA	
3	ORG & BLU	PF1 SIMULTANEOUS WITH DR1 DC ALTERNATES WITH PC DA ALTERNATES WITH PA	
4	ORG & WHT/BLK	SAME AS MODE 2	
5	ORG & BLU & WHT/BLK	SAME AS MODE 2	
6	BLU	SAME AS MODE 3	
7	WHT/BLK	SAME AS MODE 2	
8	BLU & WHT/BLK	SAME AS MODE 2	

CONTROL WIRES FOR OPTIONAL HALOGENS

CONTROL WIRE ACTIVATED	HALOGEN LAMP	
RED/WHITE	DR1 & PR1	(SPLIT REAR WORK)
BROWN	DF1 & PF1	(SPLIT TAKEDOWN)
GRAY	DA	(DRIVER ALLEY)
YELLOW	PA	(PASSENGER ALLEY)

NOTE: GREEN control wire activates high intensity to strobes.
Apply +12vdc to appropriate control wire to activate desired function.