930N-5606-0022 FLASH PATTERN

LIGHTBAR LAMP CONFIGURATION

DF3 DF2 DF1 PF1 PF2 PF3
DC PC
DA PA
DR3 DR2 DR1 PR1 PR2 PR3

MODE	CONTROL WIRES ACTIVATED	LAMP OPERATION	
		REAR / ALLEY STROBES (LOOP NOT CUT)	FRONT / CORNER STROBES (LOOP CUT)
1	ORG	DR3 & PR3 SIMULTANEOUS AND ALTERNATE WITH DR2 & PR2 SIMULTANEOUS DR1 ALTERNATES WITH PR1 DA ALTERNATES WITH PA	DF3 & PF3 SIMULTANEOUS AND ALTERNATE WITH DF2 & PF2 SIMULTANEOUS DF1 ALTERNATES WITH PF1 DC ALTERNATES WITH PC
2 ARROW PLUS	ORG & BLU	SAME AS MODE 1	DF3, DF3 & DF2, DF2 & DF1, DF1 & PF1, PF1 & PF2, PF2 & PF3, PF3, REPEAT DC ALTERNATES WITH PC
3 ARROW PLUS	ORG & WHT/BLK	SAME AS MODE 1	PF3, PF3 & PF2, PF2 & PF1, PF1 & DF1, DF1 & DF2, DF2 & DF3, DF3, REPEAT DC ALTERNATES WITH PC
4 CENTER OUT PLUS	ORG & BLU & WHT/BLK	SAME AS MODE 1	DF1 & PF1, DF2 & DF1 & PF1 & PF2, DF3 & DF2 & PF2 & PF3, DF3 & PF3, REPEAT DC ALTERNATES WITH PC
5 ARROW	BLU	NONE	DF3, DF3 & DF2, DF2 & DF1, DF1 & PF1, PF1 & PF2, PF2 & PF3, PF3, REPEAT
6 ARROW	WHT/BLK	NONE	PF3, PF3 & PF2, PF2 & PF1, PF1 & DF1, DF1 & DF2, DF2 & DF3, DF3, REPEAT
7 CENTER OUT	BLU & WHT/BLK	NONE	DF1 & PF1, DF2 & DF1 & PF1 & PF2, DF3 & DF2 & PF2 & PF3, DF3 & PF3, REPEAT

CONTROL WIRES FOR OPTIONAL HALOGENS

CONTROL WIRE ACTIVATED	HALOGEN LAMP	
RED/WHITE	DR1 & PR1	SPLIT REAR WORK
BROWN	DF1 & PF1	SPLIT TAKEDOWN
GRAY	DA	DRIVER ALLEY
YELLOW	PA	PASSENGER ALLEY

CONTROL WIRE FOR OPTIONAL 930-PRE2-1C PREEMPTION EMITTER

BRN/WHT	DF1	PREEMPTION EMITTER SIGNAL

NOTE: GREEN control wire activates high intensity to strobes.
Apply +12vdc to appropriate control wire to activate desired function.