930N-5606-0029 FLASH PATTERN

LIGHTBAR LAMP CONFIGURATION

DF3 DF2 DF1 PF1 PF2 PF3
DC PC
DA PA
DR3 DR2 DR1 PR1 PR2 PR3

MODE	CONTROL WIRES ACTIVATED	LAMP OPERATION	
		REAR / ALLEY STROBES	FRONT / CORNER STROBES
0	NONE	NONE	NONE
1 (REAR ONLY)	ORG	DR3 & PR3 SIMULTANEOUS AND ALTERNATE WITH DR2 & PR2 SIMULTANEOUS	NONE
2 (FRONT & ALLEY)	ORG & BLU	DA ALTERNATES WITH PA	DF3 & PF3 SIMULTANEOUS AND ALTERNATE WITH DF2 & PF2 SIMULTANEOUS (6 PULSES PER BURST) DC ALTERNATES WITH PC (3 PULSES PER BURST)
3 (360 +)	ORG & BLU & WHT/BLK	DR3, PR3 & DA SIMULTANEOUS AND ALTERNATE WITH DR2, PR2 & PA SIMULTANEOUS	SAME AS MODE 2
RIGHT ARROW	BLU	DR3, DR3 & DR2, DR2 & PR2, PR2 & PR3, PR3, DA & PA, REPEAT	DF3 & PF3 SIMULTANEOUS AND ALTERNATE WITH DF2 & PF2 SIMULTANEOUS
LEFT ARROW	WHT/BLK	PR3, PR3 & PR2, PR2 & DR2, DR2 & DR3, DR3, DA & PA, REPEAT	DF3 & PF3 SIMULTANEOUS AND ALTERNATE WITH DF2 & PF2 SIMULTANEOUS
CENTER OUT	BLU & WHT/BLK	DR2 & PR2, DR3 & DR2 & PR2 & PR3, DR3 & PR3, DA & PA, REPEAT	DF3 & PF3 SIMULTANEOUS AND ALTERNATE WITH DF2 & PF2 SIMULTANEOUS

CONTROL WIRES FOR OPTIONAL HALOGENS

CONTROL WIRE ACTIVATED	HALOGEN LAMP	
RED/WHITE	PF1	(TAKEDOWN)
BROWN	DF1	(TAKEDOWN
BROWN/WHITE	PR1	(REAR WORK)
GRAY	DR1	(REAR WORK)
YELLOW	DA & PA	(ALLEY LAMPS)

NOTE: GREEN control wire activates high intensity to strobes.
Apply +12vdc to appropriate control wire to activate desired function.