930N-5606-0038 FLASH PATTERN

LIGHTBAR LAMP CONFIGURATION

DF3 DF2 DF1 PF1 PF2 PF3
DC PC
DA PA
DR3 DR2 DR1 PR1 PR2 PR3

MODE	CONTROL WIRES ACTIVATED	LAMP OPERATION	
		REAR / ALLEY STROBES	FRONT / CORNER STROBES
1	ORG & WHT/BLK	DR3 & PR3 SIMULTANEOUS AND ALTRNATE WITH DR2 & PR2 SIMULTANEOUS (6 PULSES PER BURST) DR1 ALTERNATES WITH PR1 (3 PULSES PER BURST) DA ALTERNATES WITH PA (3 PULSES PER BURST)	DF3 & PF3 SIMULTANEOUS AND ALTERNATE WITH DF2 & PF2 SIMULTANEOUS (6 PULSES PER BURST) DC ALTERNATES WITH PC (3 PULSES PER BURST)
2 *OPTIONAL PREEMPTION Front Strobes Emitting	ORG & BLU & WHT/BLK	SAME AS MODE 1	DF3 & PF3 SIMULTANEOUS AND ALTERNATE WITH DF2 & PF2 SIMULTANEOUS (6 PULSES PER BURST) DC ALTERNATES WITH PC (3 PULSES PER BURST) *PREEMPTION FLASH RATE*
RIGHT ARROW	BLU	DR3, DR3 & DR2, DR2 & DR1 & PR1 DR1 & PR1 & PR2, PR2 & PR3, PR3, DA & PA, REPEAT	DF3 & PF3 SIMULTANEOUS AND ALTERNATE WITH DF2 & PF2 SIMULTANEOUS
LEFT ARROW	WHT/BLK	PR3, PR3 & PR2, PR2 & PR1 & DR1 PR1 & DR1 & DR2, DR2 & DR3, DR3, DA & PA, REPEAT	DF3 & PF3 SIMULTANEOUS AND ALTERNATE WITH DF2 & PF2 SIMULTANEOUS
CENTER OUT	BLU & WHT/BLK	DR1 & PR1, DR2 & DR1 & PR1 & PR2, DR3 & DR2 & PR2 & PR3, DR3 & PR3, DA & PA, REPEAT	DF3 & PF3 SIMULTANEOUS AND ALTERNATE WITH DF2 & PF2 SIMULTANEOUS

NOTE: This Lightbar is SET for HIGH INTENSITY

For low intensity to strobes, GROUND the GREEN control wire.

Apply +12vdc to all other control wires to activate desired function.

For operation with a Tomar 940N-DCP or 940N-SIREN, use Profile N2.

CONTROL WIRES FOR OPTIONAL HALOGENS

CONTROL WIRE ACTIVATED		HALOGEN LAMP	
BROWN		PF1	(TAKEDOWN or FRONT FLASHER)
RED/WHITE		DF1	(TAKEDOWN or FRONT FLASHER)
GRAY		DA	(DRIVER ALLEY)
YELLOW		PA	(PASSENGER ALLEY)
BRN/WHITE		DR1 & PR1	(REAR WORK or REAR FLASHER)
	or	FC	(PRE2-1C Emitter Option)