930N-5606 FLASH PATTERN

LIGHTBAR LAMP CONFIGURATION

DF3 DF2 DF1 PF1 PF2 PF3
DC PC
DA PA
DR3 DR2 DR1 PR1 PR2 PR3

MODE	CONTROL WIRES ACTIVATED	LAMP OPERATION	
		REAR / ALLEY STROBES	FRONT / CORNER STROBES
1	ORG (ALL STROBES)	DR3 & PR3 SIMULTANEOUS AND ALTERNATE WITH DR2 & PR2 SIMULTANEOUS (6 PULSES PER BURST) DR1 ALTERNATES WITH PR1 DA ALTERNATES WITH PA (3 PULSES PER BURST)	DF3 & PF3 SIMULTANEOUS AND ALTERNATE WITH DF2 & PF2 SIMULTANEOUS (6 PULSES PER BURST) DF1 ALTERNATES WITH PF1 DC ALTERNATES WITH PC (3 PULSES PER BURST)
2	ORG & BLU (RIGHT ARROW PLUS)	DR3, DR3 & DR2, DR2 & DR1, DR1 & PR1, PR1 & PR2, PR2 & PR3, PR3, DA & PA, REPEAT	SAME AS MODE 1
3	ORG & WHT/BLK (LEFT ARROW PLUS)	PR3, PR3 & PR2, PR2 & PR1, PR1 & DR1, DR1 & DR2, DR2 & DR3, DR3, DA & PA, REPEAT	SAME AS MODE 1
4	ORG & BLU & WHT/BLK (CENTER OUT PLUS)	DR1 & PR1, DR2 & DR1 & PR1 & PR2, DR3 & DR2 & PR2 & PR3, DR3 & PR3, DA & PA, REPEAT	SAME AS MODE 1
5	BLU (RIGHT ARROW)	SAME AS MODE 2	NONE
6	WHT/BLK (LEFT ARROW)	SAME AS MODE 3	NONE
7	BLU & WHT/BLK (CENTER OUT)	SAME AS MODE 4	NONE

NOTE: GROUNDING the GREEN control wire activates low intensity to strobes. Apply +12vdc to all other control wires to activate desired function.

CONTROL WIRES FOR OPTIONAL HALOGENS

CONTROL WIRE ACTIVATED	HALOGEN LAMP	
RED/WHITE	DR1 & PR1	SPLIT REAR WORK or SPLIT FLASHER
BROWN	DF1 & PF1	SPLIT TAKEDOWN or SPLIT FLASHER
GRAY	DA	DRIVER ALLEY
YELLOW	PA	PASSENGER ALLEY
BRN/WHT	DF2 or PF2	SPLIT CA STEADYBURN RED