930N-6407-PS02 FLASH PATTERN

LIGHTBAR LAMP CONFIGURATION

DF3 DF2 DF1 FC PF1 PF2 PF3
DC PC
DA PA
DR3 DR2 DR1 RC PR1 PR2 PR3

MODE	CONTROL WIRES ACTIVATED	LAMP OPERATION	
		REAR / ALLEY STROBES & FLASHER	FRONT / CORNER STROBES
1	ORG & BLU (CLEARING THE RIGHT OF WAY)	DR3 & PR3 SIMULTANEOUS AND ALTERNATE WITH DR1 & PR1 SIMULTANEOUS (6 PULSES PER BURST) DR2 ALTERNATES WITH PR2 (3 PULSES PER BURST) DA ALTERNATES WITH PA (3 PULSES PER BURST) HALOGEN FLASHERS DA ALTERNATES WITH PA	DF3 & PF3 SIMULTANEOUS AND ALTERNATE WITH DF1 & PF1 SIMULTANEOUS (6 PULSES PER BURST) DF2 ALTERNATES WITH PF2 (3 PULSES PER BURST) DC ALTERNATES WITH PC (3 PULSES PER BURST)
2	BLU (BLOCKING THE RIGHT OF WAY)	SAME AS MODE 1	DF3 & PF3 SIMULTANEOUS AND ALTERNATE WITH DF2 & PF2 SIMULTANEOUS (6 PULSES PER BURST) DC ALTERNATES WITH PC (3 PULSES PER BURST)

OPTIONAL 930-PRE PREEMPTION EMITTER

Forward facing strobes will emit a High or Low priority preemption signal

C.R.O.W.	**PREEMPTION SIGNAL EMITTED**
C.R.O.W. + WHT/BLK	Standard NEOBE® Flash Rate

OPTIONAL 930-PRE2-1C SINGLE HEAD PREEMPTION EMITTER

FC strobe will emit a High or Low priority preemption signal

C.R.O.W.	Standard NEOBE® Flash Rate
C.R.O.W. + WHT/BLK	**PREEMPTION SIGNAL EMITTED**

When ordering a Preemption system, please specify High or Low priority for factory configuration

NOTE:

1. **The 930N-6407-PS02 Light Bar is factory wired for High Intensity operation to meet NFPA specifications.**
2. **Apply +12vdc to appropriate control wire to activate desired function.**