930N-6407 FLASH PATTERN

LIGHTBAR LAMP CONFIGURATION

DF3 DF2 DF1 FC PF1 PF2 PF3
DC PC
DA PA
DR3 DR2 DR1 RC PR1 PR2 PR3

MODE	CONTROL WIRES ACTIVATED	LAMP OPERATION	
		REAR / ALLEY STROBES	FRONT / CORNER STROBES
1	ORG (ALL STROBES)	DR3 & PR3 SIMULTANEOUS AND ALTERNATE WITH DR2 & PR2 SIMULTANEOUS (6 PULSES PER BURST) DR1 ALTERNATES WITH PR1 DA ALTERNATES WITH PA (3 PULSES PER BURST)	DF3 & PF3 SIMULTANEOUS AND ALTERNATE WITH DF2 & PF2 SIMULTANEOUS (6 PULSES PER BURST) DF1 ALTERNATES WITH PF1 DC ALTERNATES WITH PC (3 PULSES PER BURST)
2	ORG & BLU (RIGHT ARROW PLUS)	DR3, DR3 & DR2, DR2 & DR1, DR1 & PR1, PR1 & PR2, PR2 & PR3, PR3, DA & PA, REPEAT	SAME AS MODE 1
3	ORG & WHT/BLK (LEFT ARROW PLUS)	PR3, PR3 & PR2, PR2 & PR1, PR1 & DR1, DR1 & DR2, DR2 & DR3, DR3, DA & PA, REPEAT	SAME AS MODE 1
4	ORG & BLU & WHT/BLK (CENTER OUT PLUS)	DR1 & PR1, DR2 & DR1 & PR1 & PR2, DR3 & DR2 & PR2 & PR3, DR3 & PR3, DA & PA, REPEAT	SAME AS MODE 1
5	BLU (RIGHT ARROW)	SAME AS MODE 2	NONE
6	WHT/BLK (LEFT ARROW)	SAME AS MODE 3	NONE
7	BLU & WHT/BLK (CENTER OUT)	SAME AS MODE 4	NONE

NOTE: This Lightbar is SET for HIGH INTENSITY

For low intensity to strobes, GROUND the GREEN control wire.

Apply +12vdc to all other control wires to activate desired function.

For operation with a Tomar 940N-DCP or 940N-SIREN, use Profile N2.

CONTROL WIRES FOR OPTIONAL HALOGENS

CONTROL WIRE ACTIVATED	HALOGEN LAMP	
RED/WHITE	RC	REAR WORK
BROWN	FC	TAKEDOWN
GRAY	DA	DRIVER ALLEY
YELLOW	PA	PASSENGER ALLEY