930N-9611 FLASH PATTERN

LIGHTBAR LAMP CONFIGURATION

DF5 DF4 DF3 DF2 DF1 FC PF1 PF2 PF3 PF4 PF5
DC PC
DA PA
DR5 DR4 DR3 DR2 DR1 RC PR1 PR2 PR3 PR4 PR5

MODE	CONTROL WIRES ACTIVATED	LAMP OPERATION	
		REAR / ALLEY STROBES	FRONT / CORNER STROBES
0	NONE	NONE	NONE
1 (ALL ON)	ORG	DR3 & PR3 SIMULTANEOUS AND ALTERNATE WITH DR2 & PR2 SIMULTANEOUS DR1 ALTERNATES WITH PR1 DA ALTERNATES WITH PA DR5 & PR5 SIMULTANEOUS DR4 ALTERNATES WITH PR4	DF3 & PF3 SIMULTANEOUS AND ALTERNATE WITH DF1 & PF1 SIMULTANEOUS DF2 ALTERNATES WITH PF2 DF4 ALTERNATES WITH PF4 DF5 & PF5 SIMULTANEOUS DC ALTERNATES WITH PC
2 (RIGHT ARROW)	BLU	DR3, DR3 & DR2, DR2 & DR1, DR1 & PR1, PR1 & PR2, PR2 & PR3, PR3, DA & PA, REPEAT	DF3 & PF3 SIMULTANEOUS AND ALTERNATE WITH DF1 & PF1 SIMULTANEOUS DF2 ALTERNATES WITH PF2 DF4 ALTERNATES WITH PF4
3 (LEFT ARROW)	WHT/BLK	PR3, PR3 & PR2, PR2 & PR1, PR1 & DR1, DR1 & DR2, DR2 & DR3, DR3, DA & PA, REPEAT	SAME AS MODE 2
4 (CENTER OUT)	BLU & WHT/BLK	DR1 & PR1, DR2 & DR1 & PR1 & PR2, DR3 & DR2 & PR2 & PR3, DR3 & PR3, DA & PA, REPEAT	SAME AS MODE 2
5 (RIGHT ARROW PLUS)	ORG & BLU	DR3, DR3 & DR2, DR2 & DR1, DR1 & PR1, PR1 & PR2, PR2 & PR3, PR3, DA & PA, REPEAT DR5 & PR5 SIMULTANEOUS DR4 ALTERNATES WITH PR4	SAME AS MODE 1
6 (LEFT ARROW PLUS)	ORG & WHT/BLK	PR3, PR3 & PR2, PR2 & PR1, PR1 & DR1, DR1 & DR2, DR2 & DR3, DR3, DA & PA, REPEAT DR5 & PR5 SIMULTANEOUS DR4 ALTERNATES WITH PR4	SAME AS MODE 1
7 (CENTER OUT PLUS)	ORG & BLU & WHT/BLK	DR1 & PR1, DR2 & DR1 & PR1 & PR2, DR3 & DR2 & PR2 & PR3, DR3 & PR3, DA & PA, REPEAT DR5 & PR5 SIMULTANEOUS DR4 ALTERNATES WITH PR4	SAME AS MODE 1

CONTROL WIRES FOR OPTIONAL HALOGENS

CONTROL WIRE ACTIVATED	HALOGEN LAMP	
GRAY	DA	(DRIVER ALLEY)
YELLOW	PA	(PASSENGER ALLEY)
BROWN	FC	(TAKEDOWN)
RED/WHITE	RC	(REAR WORK)

NOTE: GREEN control wire activates high intensity to strobes.
Apply +12vdc to appropriate control wire to activate desired function.