930N1-8009-0053 FLASH PATTERN

aka 930N1-8009-HOOV

LIGHTBAR LAMP CONFIGURATION

DF4 DF3 DF2 DF1 FC PF1 PF2 PF3 PF4
DC PC
DA PA
DR4 DR3 DR2 DR1 RC PR1 PR2 PR3 PR4

MODE	CONTROL WIRES ACTIVATED	LAMP OPERATION	
		FRONT / CORNER / ALLEY STROBES	ALLEY HALOGENS
1	ORANGE & BLUE & WHITE/BLACK & YEL (CLEARING THE RIGHT OF WAY)	DF4, DA & PC SIMULTANEOUS AND ALTERNATE WITH PF4, PA & DC SIMULTANEOUS (6 PULSES PER BURST) DF3 & PF3 SIMULTANEOUS AND ALTERNATE WITH DF2 & PF2 SIMULTANEOUS (6 PULSES PER BURST) DF1 ALTERNATES WITH PF1 (3 PULSES PER BURST)	DA ALTERNATES WITH PA
2	ORANGE & BLUE & YEL (BLOCKING THE RIGHT OF WAY)	DF4 & DA SIMULTANEOUS AND ALTERNATE WITH PF4 & PA SIMULTANEOUS (6 PULSES PER BURST) DF3 & PF3 SIMULTANEOUS AND ALTERNATE WITH DF2 & PF2 SIMULTANEOUS (6 PULSES PER BURST)	DA ALTERNATES WITH PA

CONTROL WIRES FOR HALOGEN FLASHER

CONTROL WIRE ACTIVATED		**HALOGEN LAMP**
BROWN	FC	FRONT FLASHER
YELLOW	DA & PA	ALLEY FLASHER

OPTIONAL 930-PRE PREEMPTION EMITTER - Forward facing strobes in C.R.O.W.

ORG + WHT/BLK + YEL + **BLU**	**PREEMPTION SIGNAL EMITTED**
ORG + WHT/BLK + YEL	Standard NEOBE® Flash Rate

OPTIONAL 930-PRE2-1C SINGLE HEAD PREEMPTION EMITTER in FC

BRN/WHT	Standard NEOBE® Flash Rate
RED/WHT or (BRN/WHT & RED/WHT)	**PREEMPTION SIGNAL EMITTED**

NOTE: 1. The GREEN control wire activates high intensity to all strobes (the lightbar must be operated in high intensity to meet NFPA specifications).
2. Apply +12vdc to the appropriate control wire to activate the desired function.