930N1-8810-PS03 FLASH PATTERN

LIGHTBAR LAMP CONFIGURATION

DF5 DF4 DF3 DF2 DF1 PF1 PF2 PF3 PF4 PF5
DC PC
DA PA
DR5 DR4 DR3 DR2 DR1 PR1 PR2 PR3 PR4 PR5

MODE	CONTROL WIRES ACTIVATED	LAMP OPERATION	
		FRONT / CORNER / ALLEY STROBES	FRONT / ALLEY HALOGENS
1	ORANGE & BLU (CLEARING THE RIGHT OF WAY)	DF5, DA & PC SIMULTANEOUS AND ALTERNATE WITH PF5, PA & DC SIMULTANEOUS (6 PULSES PER BURST) DF4 & PF4 SIMULTANEOUS AND ALTERNATE WITH DF3 & PF3 SIMULTANEOUS (6 PULSES PER BURST) DF2 ALTERNATES WITH PF2 (3 PULSES PER BURST)	DF1 ALTERNATES WITH PF1 DA ALTERNATES WITH PA
2	BLU (BLOCKING THE RIGHT OF WAY)	DF5, DA & PC SIMULTANEOUS AND ALTERNATE WITH PF5, PA & DC SIMULTANEOUS (6 PULSES PER BURST) DF4 & PF4 SIMULTANEOUS AND ALTERNATE WITH DF3 & PF3 SIMULTANEOUS (6 PULSES PER BURST) DF2 ALTERNATES WITH PF2 (3 PULSES PER BURST)	DA ALTERNATES WITH PA

OPTIONAL 930-PRE PREEMPTION EMITTER

Forward facing strobes will emit a High or Low priority preemption signal

C.R.O.W.	**PREEMPTION SIGNAL EMITTED**
C.R.O.W. + WHT/BLK	Standard NEOBE® Flash Rate

OPTIONAL 930-PRE2-1C SINGLE HEAD PREEMPTION EMITTER

FC strobe will emit a High or Low priority preemption signal

C.R.O.W.	Standard NEOBE® Flash Rate
C.R.O.W. + WHT/BLK	**PREEMPTION SIGNAL EMITTED**

NOTE:

1. **The 930N1-8810-PS03 Light Bar is factory wired for High Intensity operation to meet NFPA specifications.**

   Apply +12vdc to appropriate control wire to activate desired function.