465NH-8009-0052 FLASH PATTERN

LIGHTBAR LAMP CONFIGURATION

DF4 DF3 DF2 DF1 FC PF1 PF2 PF3 PF4
DC PC

MODE	CONTROL WIRES ACTIVATED	LAMP OPERATION
		FRONT / CORNER STROBES
1	ORG & BLU	DF3 & PF3 SIMULTANEOUS AND ALTERNATE WITH DF1 & PF1 SIMULTANEOUS (6 PULSES PER BURST)
2	ORG & BLU & WHT/BLK	DF3 & PF3 SIMULTANEOUS AND ALTERNATE WITH DF1 & PF1 SIMULTANEOUS (6 PULSES PER BURST) DC ALTERNATES WITH PC (3 PULSES PER BURST)

CONTROL WIRES FOR HALOGENS

CONTROL WIRE ACTIVATED	HALOGEN LAMP
BRN	DF4
YEL	DF2
BRN/WHT	FC
GRY	PF2
RED/WHT	PF4

NOTE: GREEN control wire activates high intensity to strobes.
Apply +12vdc to appropriate control wire to activate desired function.