465NH-8009 FLASH PATTERN

LIGHTBAR LAMP CONFIGURATION

DF4 DF3 DF2 DF1 FC PF1 PF2 PF3 PF4
DC PC

MODE	CONTROL WIRES ACTIVATED	LAMP OPERATION FRONT / CORNER STROBES
0	NONE	NONE
1	ORG	DF4 & DF2 SIMULTANEOUS AND ALTERNATE WITH PF4 & PF2 SIMULTANEOUS
2	ORG & BLU	DF4, DF3, DF2 & DF1 SIMULTANEOUS AND ALTERNATE WITH PF4, PF3, PF2 & PF1 SIMULTANEOUS
3	ORG & BLU & WHT/BLK	DF4, DF3, DF2, DF1 & PC SIMULTANEOUS AND ALTERNATE WITH PF4, PF3, PF2, PF1 & DC SIMULTANEOUS
4	BLU (STROBES ONLY)	DF4, DF3, & DF1 SIMULTANEOUS AND ALTERNATE WITH PF4, PF3, & PF1 SIMULTANEOUS
5	WHT/BLK (HALOGENS ONLY MODE 1)	DF2 ALTERNATES WITH PF2
6	ORG & WHT/BLK (HALOGENS ONLY MODE 2)	DF2 & PC SIMULTANEOUS AND ALTERNATE WITH PF2 & DC SIMULTANEOUS

CONTROL WIRES FOR OPTIONAL HALOGEN

CONTROL WIRE ACTIVATED	**OPERATION**
RED/WHITE	FC (TAKEDOWN)

CONTROL WIRES FOR OPTIONAL PRE2-1C

CONTROL WIRE ACTIVATED	**FC STROBE LAMP**
BRN	ACTIVATE PREEMPTION EMITTER

CONTROL WIRES FOR OPTIONAL ICC MARKER LIGHTS

CONTROL WIRE ACTIVATED	
BRN/WHT	ACTIVATE ICC MARKER LIGHTS

NOTE: GREEN control wire activates high intensity to strobes.
Apply +12vdc to appropriate control wire to activate desired function.
TAKEDOWN and PREEMPTION options cannot be ordered together.