465NH-6407 FLASH PATTERN

LIGHTBAR LAMP CONFIGURATION

DF3 DF2 DF1 FC PF1 PF2 PF3
DC PC

MODE	CONTROL WIRES ACTIVATED	LAMP OPERATION
		FRONT / CORNER STROBES
1	ORG	DF2 ALTERNATES WITH PF2
2	ORG & BLU	DF3, PF2 & DF1 SIMULTANEOUS AND ALTERNATE WITH PF3, DF2 & PF1 SIMULTANEOUS
3	ORG & BLU & WHT/BLK	DF3, PF2, DF1 & DC SIMULTANEOUS AND ALTERNATE WITH PF3, DF2, PF1 & PC SIMULTANEOUS
4	BLU (STROBES ONLY)	DF3 & DF1 SIMULTANEOUS AND ALTERNATE WITH PF3 & PF1 SIMULTANEOUS
5	WHT/BLK (HALOGENS ONLY MODE 1)	DF2 ALTERNATES WITH PF2
6	ORG & WHT/BLK (HALOGENS ONLY MODE 2)	DF2 & PC SIMULTANEOUS AND ALTERNATE WITH PF2 & DC SIMULTANEOUS

OPTIONAL CONTROL WIRES

CONTROL WIRE ACTIVATED	OPERATION
BROWN	FC (TAKEDOWN)

NOTE: GREEN control wire activates high intensity to strobes.
Apply +12vdc to appropriate control wire to activate desired function.