465NH-8810-0085 FLASH PATTERN

LIGHTBAR LAMP CONFIGURATION

DF5 DF4 DF3 DF2 DF1 PF1 PF2 PF3 PF4 PF5
DC PC

MODE	CONTROL WIRES ACTIVATED	LAMP OPERATION FRONT / CORNER STROBES & HALOGENS
0	NONE	NONE
1 ALL ON	ORG	STROBES DF5 & PC SIMULTANEOUS AND ALTERNATES WITH PF5 & DC SIMULTANEOUS HALOGENS DF4 & PF4 SIMULTANEOUS AND ALTERNATES WITH DF3 & PF3 SIMULTANEOUS DF1 ALTERNATES WITH PF1
RIGHT ARROW	BLU	HALOGENS DF4, DF4 & DF3, DF3 & DF1, DF1 & PF1, PF1 & PF3, PF3 & PF4, PF4 REPEAT
LEFT ARROW	WHT/BLK	HALOGENS PF4, PF4 & PF3, PF3 & PF1, PF1 & DF1, DF1 & DF3, DF3 & DF4, DF4 REPEAT
CENTER OUT	BLU & WHT/BLK	HALOGENS DF1 & PF1, DF3 & DF1 & PF1 & PF3, DF4 & DF3 & PF3 & PF4, DF4 & PF4 REPEAT

CONTROL WIRES FOR OPTIONAL HALOGENS

CONTROL WIRE ACTIVATED	HALOGEN LAMP	
RED/WHITE	PF2	(TAKEDOWN)
BROWN	DF2	(TAKEDOWN)

NOTE: GREEN control wire activates high intensity to strobes.
Apply +12vdc to appropriate control wire to activate desired function.