465NH-6407-0100 FLASH PATTERN

LIGHTBAR LAMP CONFIGURATION

DF3 DF2 DF1 PF1 PF2 PF3
DC PC

MODE	CONTROL WIRES ACTIVATED	LAMP OPERATION FRONT / CORNER STROBES
1	ORG (HALOGEN ONLY)	DF1 & PF1 SIMULTANEOUS AND ALTERNATE WITH DF3, PF3 & FC SIMULTANEOUS
2	BLU (STROBE ONLY)	DC & PC SIMULTANEOUS AND ALTERNATE WITH DF2 & PF2 SIMULTANEOUS
3	ORG & BLU	DC, DF1, PF1 & PC SIMULTANEOUS AND ALTERNATE WITH DF3, DF2, PF2, PF3 & FC SIMULTANEOUS

OPTIONAL CONFIGURATION – One or Both may be selected

OPTION	CONTROL WIRES ACTIVATED	LAMP OPERATION FRONT / CORNER STROBES
REVERSE SYCHRONIZATION OF FC	ORG (HALOGEN ONLY)	DF1, PF1 & FC SIMULTANEOUS AND ALTERNATE WITH DF3 & PF3 SIMULTANEOUS
OPTIONAL STROBES IN DF1 & PF1 REPLACES HALOGENS	BLU (STROBE ONLY)	DC, DF1 & PC SIMULTANEOUS AND ALTERNATE WITH DF2, PF1 & PF2 SIMULTANEOUS

CONTROL WIRES FOR OPTIONAL HALOGEN

CONTROL WIRE ACTIVATED		**OPERATION**
BROWN	DF1	SPLIT or SOLID TAKEDOWN
RED/WHITE	PF1	SPLIT or SOLID TAKEDOWN

CONTROL WIRES FOR OPTIONAL PRE2-1C

CONTROL WIRE ACTIVATED	**FC STROBE LAMP**
BRN/WHT	ACTIVATE PREEMPTION EMITTER

NOTE: GREEN control wire activates high intensity to strobes.
Apply +12vdc to appropriate control wire to activate desired function.