465NH-8009-0113 FLASH PATTERN

LIGHTBAR LAMP CONFIGURATION

DF4 DF3 DF2 DF1 FC PF1 PF2 PF3 PF4
DC PC

CONTROL WIRES FOR HALOGEN LAMPS

GRY	DF4
BLUE	DF2L
WHT/BLK	DF2R & PF2L
ORANGE	DF1
BRN	FC
BRN/WHT	PF1
YEL	PF2R
RED/WHT	PF4

CONTROL WIRE FOR STROBE LAMPS

GRN	DC & PF3 SIMULTANEOUS AND ALTERNATES WITH PC & DF3 SIMULTANEOUS

NOTE: Apply +12vdc to the appropriate control wire to activate desired lamp.