465NH-6407-0123 FLASH PATTERN

LIGHTBAR LAMP CONFIGURATION

DF3 DF2 DF1 FC PF1 PF2 PF3
DC PC

MODE	WIRES ACTIVATED	HALOGENS
1	ORG	DC, DF1 & PF3 SIMULTANEOUS AND ALTERNATE WITH PC, PF1 & DF3 SIMULTANEOUS

NOTE: Apply +12vdc to the appropriate control wire to activate.

DF2, FC & PF2 Lamp Positions, each with PC0161-WP2 Cable Kit 20C-WP2 20 Feet provided for customer to connect to remote strobe power supply