

**950N-5606 NEOBE LIGHTBAR**  
**PS02 - FACTORY SETTING FLASH PATTERN**

NFPA application # 1

**Mode C.R.O.W.**

+12 vdc **ORANGE & BLUE** Control Wires Activated

Front & Corner Warning Lamps: *Inboard/Outboard with Corner - 6 pulse Neobe*

Rear & Side Warning Lamps: *Inboard/Outboard with Sides - 6 pulse Neobe*

**Mode B.R.O.W.**

+12 vdc **BLUE** Control Wires Activated

Front & Corner Warning Lamps: *In/Out with Corners (DF1/PF1 off) - 6 pulse Neobe*

Rear & Side Warning Lamps: *Inboard/Outboard with Sides - 6 pulse Neobe*

NFPA application # 2

**Mode C.R.O.W.**

+12 vdc **ORANGE** Control Wire Activated

Front & Corner Warning Lamps: *Inboard/Outboard with Corners - 6 pulse Neobe*

Rear & Side Warning Lamps: *Inboard/Outboard with Sides - 6 pulse Neobe*

**Mode B.R.O.W.**

+12 vdc **ORG & WHT/BLK** Control Wires Activated

Front & Corner Warning Lamps: *In/Out with Corners (DF1/PF1 off) - 6 pulse Neobe*

Rear & Side Warning Lamps: *Inboard/Outboard with Sides - 6 pulse Neobe*

**Traffic Directional Modes on Rear Lamps - Left, Right or Center Out - 6 pulse Neobe**

Front Warning Lamps: *Inboard/Outboard with Corner - 6 pulse Neobe*

**Any other combinations of the ORG, BLUE and WHITE/BLACK control wires = OFF.**

**See 950N-5606 Appendix A for additional 950N-5606 Control & Power Wire functions.**

The 950N-5606 NFPA configuration can be used as part of the Tomar Pumper System-2 NFPA 1901 Certified System.

Configure lamp colors as follows:

- Forward facing lamps may be Red, Blue, or ½ Red and Blue.
- Select Clear lamps in DF1/PF1 or DF1, PF1, DC & PC.
- Select Amber Alley Halogen Flasher in DA & PA
- Select Amber lamps in DR1/PR1.
- All other Rear facing lamps may be Red, Blue or Amber.
- Lightbar operates in High Power, do not activate Low Power.

NFPA compatible flash patterns are Inboard/Outboard or Left/Right