

MODEL 800/1250 CLEAR LENS DUST COVER

MOUNTING INSTRUCTION SHEET

- 1. Place o-ring around outside of strobe lens, so that it rests evenly in the groove closest to clamp ring (as shown in Figure A).
- 2. Peel backing off tape on inside of dust cover (Figure B).
- 3. Slowly place clear lens dust cover over strobe lens. Push down firmly with a <u>slight</u> twisting motion to secure a tight seal (Figure C).
- 4. The dust cover is now permanently attached to the strobe lens (Figure D).

