

930N-4004-0093 FLASH PATTERN

LIGHTBAR LAMP CONFIGURATION

	DF2	DF1	PF1	PF2	
DC					PC
DA					PA
	DR2	DR1	PR1	PR2	

MODE	CONTROL WIRES ACTIVATED	LAMP OPERATION	
		REAR STROBES	FRONT / CORNER STROBES
1	WHT/BLK	NONE	DF2 & PF2 SIMULTANEOUS AND ALTERNATE WITH DF1 & PF1 SIMULTANEOUS (6 PULSES PER BURST)
2	WHT/BLK & ORG	NONE	DF2 & PF2 SIMULTANEOUS AND ALTERNATE WITH DF1 & PF1 SIMULTANEOUS (6 PULSES PER BURST) DC ALTERNATES WITH PC (3 PULSES PER BURST)
3	WHT/BLK & ORG & BLU (ALL ON)	DR2 ALTERNATES WITH PR2 (6 PULSES PER BURST)	SAME AS MODE 2

CONTROL WIRES FOR OPTIONAL HALOGEN LAMPS

CONTROL WIRE ACTIVATED	HALOGEN LAMP
BROWN	DF1 & PF1 (SPLIT TAKEDOWN)
GRAY	DA (DRIVER ALLEY)
YELLOW	PA (PASSENGER ALLEY)

CONTROL WIRES FOR ONE OPTIONAL DUAL MODE HALOGEN

CONTROL WIRE ACTIVATED	HALOGEN LAMP
BROWN	DF1 & PF1 (SPLIT TAKEDOWN FLASHER)
BRN & BRN/WHT**	DF1 & PF1 (SPLIT TAKEDOWN STEADYBURN)
OR	
RED/WHITE	DR1 & PR1 (DUAL REAR FLASHER)
RED/WHT & BRN/WHT**	DR1 & PR1 (DUAL REAR WORK STEADYBURN)

**additional option required

**NOTE: GREEN control wire activates high intensity to strobes.
Apply +12vdc to appropriate control wire to activate desired function.**